

Инструменты




Карандаш



Сверло



Силикон



Отвертка




Рулетка



уровень




Дрель




МОЛОТОК


Комплектующие




A X1




B X4




C X4



D X1



E X2




F X4




G X2


The following components are packed in another products which would be matched with this product.



J X4



K X1



L X4

Схема сборки

